
# **SERVICE MANUAL**

MICRO TALK-BOOK



TRC5800



141 897 02


## **SPECIFICATIONS**

Power Source DC 3V (UM-3, HP 7, AA Cell, Mignonzellen, R6) x 2 Output Power	Fast Forward Time
Current Consumption (at VR min)	200 – 7000Hz (15/16 ips.)
Record mode 100 mA	Erase Ratio (Overall) 50dB
Playback mode 95mA	Signal to Noise Ratio
Fast Forward mode 100 mA	40dB
Rewind mode 110mA	Crosstalk (with Fe2O3)
Recording System AC Bias	Track to Track
Erasing System Magnet Erasing	Harmonic Distortion (K3) 6%
Tape Speed	Terminal Impedance
1	MIC
2	EXT. Speaker
Wow & Flutter 0.6% (RMS)	


## **DISASSEMBLY INSTRUCTIONS**

#### CABINET BOTTOM REMOVAL

- Remove the microcassette tape from the compartment by pressing the STOP/EJECT button.
- Turn over the unit on a clean soft surface and remove the battery compartment lid as illustrated. Then, unload the two dry batteries.




- 3. Detach the Cabinet Bottom by removing five screws (1-5).
- Remove the Escutcheon by pulling it in the direction of the arrow.



5. Reassemble in reverse order.

### FRONT CABINET REMOVAL

- Detach the Cabinet Bottom and remove the screw (6) fastening the Front Cabinet.
- 2. Detach the Front Cabinet by pulling it in the direction of the arrow, noting the leads.




#### NOTE

The leads are connected to the built-in microphone and L.E.D. Unsolder the leads from the Amplifier P.C.Board if necessary.

- 3. Pull out the Pause Switch button from the PAUSE switch if necessary.
- 4. Reassemble in reverse order.

#### FRAME REMOVAL


 Detach the Cabinet Bottom and Front Panel and then, remove the leads indicated in the illustration from the Amplifier P.C.Board.



2. Remove the Post (7) which fastens the Frame to the Mechanism Chassis and four screws (8-11) as illustrated.

## DISASSEMBLY INSTRUCTIONS (Continued)


3. Remove the Frame by lifting it in the direction of the arrow as illustrated with the Mechanism Chassis mounted on the P.C.Board. The Handle Holders will be removed together with the Frame.



4. Reassemble in reverse order.

### **CABINET TOP REMOVAL**


- 1. Remove the Cabinet Bottom and Front Cabinet, and two screws (12 & 13) fastening the Cabinet Top.
- Slightly lift the Cabinet Top in the direction of the arrow (A) and slide it in the direction of the arrow (B) to remove it as illustrated.




3. Reassemble in reverse order.

### AMPLIFIER P.C.B. REMOVAL

- Detach the Cabinet Bottom and Front Cabinet by following the instructions for their removals and unsolder the Shield Plate.
- 2. Remove the seven leads indicated in the illustration.
- 3. Pull up Condenser C8 and remove the leads arranged by the Condenser.



- 4. Remove three screws (14-16) fastening the Amplifier P.C.Board, the Pause Switch Button, and the Tape Speed Select Switch.
- 5. Remove the P.C.B. by lifting it as illustrated.



#### NOTE:

- \* After arranging the leads with Condenser C8, bend the legs of the Condenser. Check that the R/P Switch Lever does not touch the Condenser by pressing the RECORD button
- \* Arrange the yellow lead along the Shield Plate to prevent noise.
- 6. Reassemble in reverse order.

### **MECHANICAL ADJUSTMENTS**

#### **GENERAL REMARKS**

- Before adjusting the mechanism of the unit, wipe the tape contacting surfaces clean as well as the rubber surfaces of the driving parts with a soft cloth soaked in alcohol. Trouble may occur because of oil and grease stains.
- Use the external power source (Constant-Voltage Regulator, 3.0V DC) whenever a repair or an adjustment work is performed.
- 3. Keep the belts clean while the adjustments are performed.

#### REQUIRED EQUIPMENTS


- Microcassette Torque Meter
- Dial Tension Gauge
- Plus Screwdriver (1.7 mm)

#### NOTE

Set the Tape Speed Select Switch to "2.4cm" and perform a repair or an adjustment work.

#### PINCH ROLLER ADJUSTMENT

- 1. Check the Pinch Roller. If the rubber surface has scratch marks or is deteriorated, replace it with a new one.
- 2. Set the unit in the playback mode and measure the pressure with the dial tension gauge by the following procedures:
  - \* Hook the dial tension gauge to the Pinch Roller and pull the Pinch Roller off the Capstan as illustrated. Then, slowly bring the Pinch Roller close to the Capstan.




- \* Measure the pressure the moment the Pinch Roller comes in contact with the Capstan and starts rotating. It should be 180 — 250g-cm.
- \* If not, replace the spring with a new one.

#### **HEAD POSITION ADJUSTMENT**

The distance between the cassette fixing pins and each Head should be as follows with the unit in the recording mode.


R/P Head .					١.				4.4 mm
Erase Head									4.5mm




The following adjustment should be performed whenever the Head has been disassembled or replaced.

#### NOTE

A cassette with the specified pin-head distances marked on it as shown can be used as a facilitating gauge for the Head Position Adjustment. (Do not use a worn cassette.)



- 1. Mount the R/P Head on the Slide Base and move the Head to the specified position. Then, tighten the fastening screws.
- Mount the Erase Head on the Erase Head Base and move the Head to the specified position. Then, tighten the fastening screws.



3. Secure the screws fastening the R/P Head and the Erase Head with paint or glue.


#### NOTE:

Secure the azimuth adjusting screw with paint or glue after the azimuth adjustment.


## MECHANICAL ADJUSTMENTS (Continued)

### TAKE-UP TORQUE ADJUSTMENT

1. Insert the microcassette torque meter into the cassette compartment and set the unit in the playback mode. Then, measure the take-up torque of the Take-up Reel. It should be 6-11g-cm.




- 2. If necessary, check the following parts.
  - \* Drive Belt
  - \* Take-up Idler
  - \* Take-up Reel
- 3. If the above described parts are stained or the rubber is deteriorated, wipe them with a soft cloth soaked in alcohol or replace them with new ones.




#### **AUTO-SHUT OFF MECHANISM**

#### FUNCTION


 When the tape has reached its end with the unit in the recording or playback mode, the tape moves the Supply Reel in the direction of the arrow A and the Supply Arm moves in the direction of the arrow B.



Because the Flywheel continues rotating, the tooth of the Flywheel pushes the section of the Supply Arm, so that the Play Lock Lever moves in the direction of the arrow C.



3. The Slide Lever, which has been locked by the Play Lock Lever, is released and sets the unit in the stop mode.



#### NOTES ON UNIT ASSEMBLY

- 1. Solder the removed leads again and arrange them as before.
- 2. Assemble the unit referring to the Schematic Diagram and the Exploded Views.

### **ELECTRICAL ADJUSTMENTS**

#### REQUIRED EQUIPMENTS

- VTVM
- Frequency Counter
- DC Constant-Voltage Regulator
- Dummy Load (8 ohm)
- Test Tapes
  - \* 3kHz test tape (Example: Olympus 3K09) for Tape Speed Adjustment
  - \* 3kHz test tape (Example: Olympus A09) for Head Azimuth Adjustment
- Alignment Bar


#### NOTE

- 1. Supply 3.0V DC from the constant-voltage regulator at the adjustments.
- Unless otherwise specified, set the Tape Speed Select Switch to "2.4cm".

#### TAPE SPEED ADJUSTMENT

#### 2.4 cm/second Adjustment

- 1. Set the Tape Speed Select Switch to "2.4cm" and remove the battery compartment lid.
- 2. Connect the frequency counter to the earphone jack as illustrated and insert the 3 kHz test tape (Example: Olympus 3K09) into the cassette compartment.



3. Turn the potentiometer (P3) in the Governor P.C.Board until the frequency counter reads 3000Hz±3% with the unit in the playback mode.


#### 1.2cm/second Adjustment

- 4. Set the Tape Speed Select Switch to "1.2cm" and play back the test tape with the above-described method.
- 5. Turn the potentiometer (P302) in the Governor P.C.Board until the frequency counter reads 1500Hz±10%.




#### **HEAD AZIMUTH ADJUSTMENT**


 Remove the Azimuth Cover as illustrated and insert the 3kHz test tape (Example: Olympus A09) into the cassette compartment.



2. Connect the VTVM to the earphone jack as illustrated and turn the azimuth adjusting screw until the VTVM reads maximum with the unit in the playback mode.



### Adjustment




3. After the adjustment, secure the azimuth adjusting screw with paint or glue.

## **ELECTRICAL ADJUSTMENTS** (Continued)

#### **CORELESS MOTOR**


The productivity of the motor used for the conventional tape recorders is very high and the large torque is obtained although the motor is very small and inexpensive. However the irregular rotation and vibration are sometimes caused because of the variation of the magnetic resistance and Wow & Flutter increase. It also has some difficulties to use the motor for a microcassette recorder.

The coreless motor used in this Model has no core in the rotor as the name shows. Only the coils are molded with resin, arranged, and used as a rotor. The functional principle of the coreless motor will be explained according to the principle of "Left-hand Rule" which has been applied to the conventional motors.



The rotor of the motor has three coils whose angles are  $90^{\circ}$  and the coils are arranged at the angle of  $120^{\circ}$  and molded with resin. The rotor consists of coils and resin. The characteristics are as follows:

- \* Light Weight
- \* Low Inertia
- \* No irregular rotations (No magnetic resistance)



Therefore, the vibration which the motor itself causes and the characteristics of Wow & Flutter are improved. The coreless motor will be well applied to the microcassette tape recorders. But the production cost will be inscreased because magnet components such as samarium (Sm) and cobalt (Co) are used to increase torque.

# PARTS LIST

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty				
- 1	PACKAGE AMPLIFIER P.C.B. ASSY										
	141 6 1419 43202	Individual Carton	1	D2	4 2029 70160	Diode, 1S953	1				
1	141 6 1449 60400		1	IC1	4 2069 70660	1 '	1				
1	141 6 2519 080 15	Poly Cover	1	IC2	4 2069 70650	1 -	1				
	141 6 2519 11190	Poly Cover	1_	Q1 Q2	4.2039.70610 4.2039.70610	1	1 1				
1	ACCESSORIES			T1		OSC Transformer	1				
<u> </u>	4 1529 70013	Earphone	1 1	T2	4 2559 70111		1 1				
1	4 1919 71131	1 .	1 1	VR1	1	Volume Control (A-10k)	1				
ł	4 2419 72301	Micro Cassette	1	S1	4 2319 73641		1				
1	141 0 2719 00300		1 1	S2		Slide Switch (Tape Speed)	1				
ļ	141 2 1819 10200			S3	4 2319 73481	The state of the s	1				
	141 6 4119 90200	Instruction Manual	1	J1 J2	4 2359 73470 4 2359 73470		1				
<u> </u>				J4	1	Ext. Power Socket	1 1				
	CABINET			F	CHIP P.C.B. ASSY	LXI. 1 OWE GOLKOT	4				
		Speaker (8 ohm)	1		<del></del>						
	4 1539 70621	Microphone	1 1	0.4	4 2269 32110	Chip P.C.B. Assy	1				
l	141 0 1119 61402		1 1	C1	CG3 3 3250 MH00A	CG 0.033 μF 25V ±20%	1				
1	141 0 1119 61500 141 0 1119 61702		1 1	C5 C10	CG2 2 2500 MH00A CG3 3 2500 MH00A	CG 0.0022 μF 50V ±20% CG 0.0033 μF 50V ±20%	1 1				
	141 0 1149 067 01	Frame Assy	1 1	C13	CG1 0 2500 KH00A	CG $0.0033 \mu f = 50V \pm 10\%$	1				
1	141 0 1219 03900	1	1	C15	CG4 7 3500 Z100A						
1	141 0 2419 00101	Azimuth Cover Assy	1	C16	CG4 7 3500 ZI00A	CG 0.047 µF 50V +80, -20%					
Ì	141 0 2719 00400	Handle Holder Assy	1	C22	CG2 2 2500 MH00A	CG 0.0022 μF 50V ±20%	1				
	141 2 1249 20901	Cassette Lid	1	C23	CG1 5 3500 ZI00A		5 1				
	141 2 1319 15600		1 1	C24	CG3 3 2500 MH00A	CG 0.0033 μF 50V ±20%	1				
	141 2 1339 21000	1	1 1	C27	CG3 3 3250 MH00A		1				
	141 2 1519 24600		1 1	R2	RG0 0 0121 JA000 RG3 3 2121 JA000		1				
	141 2 1619 62000 141 2 1649 12800		1 1	R3	RG2 7 2121 JA000	1	1				
	141 2 3899 09600	1	1 1	R4	RG5 6 3121 JA000	RG 56k ohm 1/8W ±5%	1				
	141 2 4119 01200	1	$\perp$ i $\mid$	R5	RG1 8 3121 JA000		1				
ļ	141 2 4219 10501	Screw	2	R6	RG1 5 3121 JA000	RG 15k ohm 1/8W ±5%	1				
	141 2 4219 10601	Screw	5	R7	RG2 2 3121 JA000	RG 22k ohm 1/8W ±5%	1				
	141 2 4219 10602	Screw	1	R8	RG3 3 3121 JA000	RG 33k ohm 1/8W ±5%	1				
1	141 2 4219 15401	Screw	2	R9	RG1 8 3121 JA000	RG 18k ohm 1/8W ±5%	1				
1	141 2 4219 18601	Screw	2	R10	RG4 7 2121 JA000	RG 4.7k ohm 1/8W ±5%	1 1				
1	141 2 4469 14500 141 2 4469 29700		1 1	R11 R12	RG4 7 1121 JA000 RG2 2 0121 KA000	1	1 1				
1	141 2 4469 32200	1	111	R13	RG1 0 2121 JA000		1 1				
	141 2 8539 34500	1	lil	R14	RG4 7 3121 JA000	1					
	141 2 3229 26700	( · ·	1	R15	RG5 6 2121 JA000		1 1				
1	141 2 4219 10500	Screw	3	R16	RG2 7 2121 JA000		1				
1	141 2 4469 17201	Cushion	1	R17	RG1 0 1121 JA000	RG 100 ohm 1/8W ±5%	1				
1	141 2 4469 23201	Cushion	2	R18	RG1 0 3121 JA000	RG 10k ohm 1/8W ±5%	1				
L	110 3 2101 70013	Spring Washer-2 M1.7	1	R19	RG5 6 3121 JA000	RG 56k ohm 1/8W ±5%	1 1				
1 .	AMPLIFIER P.C.B.	ASSY		R20	RG1 5 0121 KA000	RG 15 ohm 1/8W ±10%	1 1				
<u> </u>		Amplifier P.C.B. Assy	11	R21 R22	RG4 7 1121 JA000 RG3 3 3121 JA000		1 1				
		Chip P.C.B. Assy		R23	RG1 8 1121 JA000		1				
	141 2 3659 14700		i	R24	RG2 7 2121 JA000		1				
	141 2 1639 31800		1 1	R25	RG1 0 5121 JA000		1				
1	141 2 4219 08900		1 1	R26	RG1 8 3121 JA000		1				
C2	CI3 3 3250 KF00C	Boundary 0.033 µF 25V ±10%	1	R27	RG1 0 0121 KA000		1				
СЗ	CD1 0 7100 0001V	Electrolytic 100 μF 10V	1 1	R28	RG5 6 0121 KA000		1				
C4	CT1 0 5100 M00SV	Tantalum $1 \mu F$ $10V \pm 20\%$	1 1	R29	RS5 6 1620 KT000		1				
C6	CT1 0 630A M00DV	Tantalum $10 \mu\text{F}$ $3V \pm 20\%$	1 1	R30	RG2 2 4121 JA000	RG 220k ohm 1/8W ±5%	1 1				
C7	CT1 0 5100 M00SV CI1 2 2250 KE00C	Tantalum 1 $\mu$ F 10V ±20% Boundary 0.0012 $\mu$ F 25V ±10%	1 1	R31	RG6 8 4121 JA000	RG 680k ohm 1/8W ±5%					
C8 C9	CT1 0 5100 M00SV	Tantalum $1 \mu F$ 10V ±20%	1 1	,	JACK P.C.B. ASSY		1				
C11	CT2 2 630A M00DV	Tantalum $22 \mu F$ $3V \pm 20\%$	1 1	J3	4 2359 74730	Jack P.C.B. Assy (Remote)	1 1				
C12	CT1 5 4350 M00DV	Tantalum 0.15 $\mu$ F 35V ±20%	1 1	1	1	Mechanism Complete	1 1				
C14	CT1 5 4350 M00DV	Tantalum 0.15 µF 35V ±20%	1 1	S4		F.F. Rewind Switch Assy	1 1				
C17	CT4 7 563A M00DV	Tantalum 4.7 µF 6.3V ±20%	1	S5		Power Switch Assy	1				
C18	CT3 3 630A M00DV	Tantalum 33 $\mu$ F 3V ±20%	1	HD1		R/P Head Assy	1				
C19	CD1 0 7100 0001V	Electrolytic 100 μF 10V	1 1	HD2	4 2429 71540	Erase Head	1				
C20	CT1 0 630A M00DV	Tantalum 10 $\mu$ F 3V $\pm 20\%$	1 1		4 2869 70430	Governor P.C.B. Assy	1 1				
C21	CT1 0 5100 M00SV	Tantalum $1 \mu F$ 10V ±20%	1 1		4 5279 70990		1				
C25	CM3 9 2101 K00SV	Mylar 0.0039 $\mu$ F 100V ±10% Tantalum 33 $\mu$ F 3V ±20%	1 1		112 3 1301 50082		9				
C26	CT3 3 630A M00DV	Tantalum 33 $\mu$ F 3V ±20%	'	1	112 3 1302 00082	E Ring M2.0	2				


## PARTS LIST (Continued)

Ref.	Part No.	Description	Q'ty
No.	MECHANISM	Description	
IN T	141 0 1249 15300	Cassette Support Assy	T 1
	141 0 1249 13300	Chassis Assy	1 1
	141 0 35 19 17800 141 0 52 19 06300	Flywheel Support Assy Flywheel Assy	
	141 0 52 19 00300	Take-up Reel Assy	1
	141 0 5369 01200	Reel Bracket Assy	1 1
	141 0 5369 01300 141 0 5419 02800	Supply Arm Assy Pinch Roller Assy	1
	141 0 5559 05600	Rewind Arm Gear Assy	1
	141 0 7319 20100 141 0 7419 23800	Slide Base Assy Stop Lever Assy	1 1
	141 0 7419 24000	Record Lever Assy	1
	141 0 74 19 24100 141 0 74 19 24200	F.F. Rewind Lever Assy Play Lock Lever Assy	1 1
	141 0 7419 24200	Click Arm Assy	i
	141 2 1219 13400	Chassis Panel	1 1
	141 2 35 19 47600 141 2 35 19 47700	Bracket Holder Motor Bracket Assy	1 1
	141 2 3529 25000	Record Crank Collar	1
	141 2 3529 25200	Supply Arm Collar Collar	1 1
	141 2 3529 25300 141 2 3529 25400	Collar	1
ŀ	141 2 3529 25500	Collar	1
	141 2 3529 25700 141 2 3769 09300	Collar Lock Lever Spacer, Erase Head	1 1
	141 2 4219 18800	Screw, Azimuth	1
	141 2 4219 19300	Screw, Flat Hd. Tapping-1 +M1.4x1.6 Screw, Pan Hd. Tapping-3 +M1.4x5	3 2
	141 2 4219 19400 141 2 4219 19500	Screw, Pan Hd. Tapping-3 +M1.4x3	
	141 2 4219 19600	Screw, Pan Hd. Tapping-2 +M1.7x2.0	
	141 2 4219 19700 141 2 4219 19800	Screw, Pan Hd. Tapping-3 +M1.7x2.5 Screw, Pan Hd. Tapping-1 +M1.7x3.6	1
	141 2 4219 19900	Screw, Pan Hd. Tapping-1 +M1.7x4.0	
	141 2 4219 20100 141 2 4219 20200	Screw, Pan Hd. Tapping-3 +M1.7x4.0 Screw, Pan Hd. Tapping-1 +M1.7x3.5	1 1
	141 2 4459 23300	Motor Cushion	1
	141 2 4539 18700 141 2 4539 18800	Washer   Washer	3
1	141 2 4539 18900	Washer	2
	141 2 4539 19000 141 2 4729 06300	Washer Lock   Lug	1
	141 2 4729 06400	Lug	1
	141 2 5319 08700	Supply Reel	1 1
	141 2 5519 33200 141 2 5519 33300	Take-up Idler Rewind Gear	1
	141 2 5649 14000	Belt Counter	1
	141 2 5649 14100 141 2 6619 02700	Drive Belt Rewind Pulley	1 1
	141 2 7319 39400	Erase Head Base	1
	141 2 7419 62200 141 2 7439 17700	Record Crank	1 1
1	141 2 8119 07500	Counter	1
	141 2 8139 05200	Counter Bracket	1 1
	141 2 8219 27100 141 2 8419 09800	Tape Guide R/P Actuating Switch Lever	1
	141 2 8519 85800	Spring, Azimuth	1
	141 2 8519 86000 141 2 8519 86100	Spring, Record Lock Spring, Record Lever	1 1
I	141 2 85 19 86200	Spring, Pinch Roller	1
	141 2 8519 86300	Spring, R/P Switch Lever	1 1
	141 2 8519 86400 141 2 8519 86500	Spring, Rewind Lever Spring, Slide Base Lock	1
	141 2 8519 86600	Spring, Supply Arm	1
	141 2 8519 86700 141 2 8519 86800	Spring, Interlock Spring, Take-up Idler	1 1
	141 2 8519 86900	Spring, Stop Lever	1
	141 2 8519 87000	Spring, Rewind Arm Gear	1 1
1	141 2 8519 87100 141 2 8519 87200	Spring, Click Arm Spring, Eject	1
	141 2 8519 89500	Spring, Erase Head	1

Ref. No.	Part No.	Description							
٨	MECHANISM								
	141 2 8539 36000	Spring, Cassette Support	1						
	141 2 8539 36100	Spring, R/P Switch	1						
	141 2 8539 36200	Spring, Cassette	1						
	141 2 8539 36500	Spring, F.F.	1						
	141 2 8539 36600	Spring, Counter	1						
	141 2 2419 23100	Veil	1						
	141 2 2899 12700	Adhesive Sheet	1 1						
	141 2 4219 10601	Screw	2						
	141 2 4219 15400	Screw	4						
	141 2 4219 17201	Screw	1 1						
1	141 2 4469 14502	Cushion	4						
l	141 2 4469 32000 141 2 4539 19400	Washer	2						
l	141 2 4539 19400	Washer	1						
	141 2 7519 43500	Post	1						
(	GOVERNOR P.C.B.	ASSY							
	4 2869 70430	Governor P.C.B. Assy	1						
C301	CC4 7 2500 YG00C	Ceramic 0.0047 µF 50V	1						
C302	CT1 0 630A M00DV	Tantalum 10 µF 3V ±20%	1						
D301	4 2029 71120	Diode, 1S2076	1						
TH301	204 5 9000 00200	Thermister, SDT20	1						
L301	4 2539 70700	Choke Coil (1 mH)	1						
P301	4 2229 73120	Potentiometer (B-200)	1						
P302	4 2229 73130	Potentiometer (B-1k)	1						
Q301	4 2039 70640	Transistor, 2SC 1213	1						
Q302	4 2039 70650	Transistor, 2SC 1311	1 1						
Q303	4 2039 70660	Transistor, 2SA728A	1						
R301	RD1 0 A251 JM000	Carbon 1.0 ohm 1/4W ±5%	1						
R302	RD1 0 A251 JM000	Garzer	1 1						
R303	RD5 1 A251 JM000	Carbon 5.1 ohm 1/4W ±5% Carbon 4.7 ohm 1/4W ±5%	1						
R304	RD4 7 A251 JM000 RP5 6 2121 JH000	Pretty 5.6k ohm 1/8W ±5%	1						
R305	RP5 6 2121 JH000	Pretty 5.6k offin 1/8W ±5%	l i						
R306 R307	RS4 7 2620 JT000	Micro 4.7k ohm 1/16W ±5%	1						
R307	RP1 5 1121 JH000	Pretty 150 ohm 1/8W ±5%	1						
R309	RP5 6 1121 JH000	Pretty 560 ohm 1/8W ±5%	l i						
R310	RP3 3 1121 JH000	Pretty 330 ohm 1/8W ±5%	1						
R311	RP3 3 1121 JH000	Pretty 330 ohm 1/8W ±5%	1						
R312	RP2 0 2121 JH000	Pretty 2.0k ohm 1/8W ±5%	1						
R313	RP1 0 2121 JH000	Pretty 1k ohm 1/8W ±5%	1						
R315	RD4 7 A501 JV000	Carbon 4.7 ohm 1/2W ±5%	1						


- NOTES: 1. Parts order must contain Model Number, Part Number and Description.
  2. Ordering quantity of screws and resistors must be multiple of 10 pcs.

## **EXPLODED VIEW**




## **EXPLODED VIEW** (Continued)

#### (Chassis Top)




## **EXPLODED VIEW** (Continued)

#### (Chassis Bottom)




# AMPLIFIER P.C.BOARD(Top View)




## **GOVERNOR P.C.BOARD**


(Top View)




(Bottom View)



## **WIRING DIAGRAM**



## **SCHEMATIC DIAGRAM**



#### NOTE

S2

S3

S4

S5

The described voltages are the values measured with the voltmeter (Internal Resistance: 1M-ohm/V at no-signal) in the playback mode.

2.4 cm/sec. OFF

OFF

OFF

TAPE SPEED Switch


PAUSE Switch

FF/REW Switch

POWER Switch

# IC, TRANSISTOR & THYRISTOR IDENTIFICATION

FRONT VI	EW BC	OTTOM VIEV	TRANSISTOR
E C B		E C B	2SA728 2SC1311 2SC2458
B C E		3 9 5 1 4 1 B C E	2SC 1213
	TER	MINAL NAM	1E
	B⇒ C⇒ E⇒	COLLECTO	)R



### **CX-184 EQUIVALENT CIRCUIT**

